

SAC graf/penTM

the most widely used data tablet

the man/computer interface that brings new speed and accuracy to commerce, industry and science—digitizing formatted and graphical information for direct entry into computers for such applications, among many others, as...

**order transmission
inventory control
computer-aided drafting
numerical-control programs
system analysis
light-pen replacement**

featuring

hard copy created during input plus high resolution, linearity, stability, precision, flexibility, and reproducibility—at low cost, with no keyboard, mouse or joystick required



The **graf/pen** Data Tablet brings new and needed facilities to the worlds of business, industry, and technology . . . gives the decision-maker the ability to enter written, drawn, or formatted material directly into a computer. Options include, among many others: display on and interaction with one or more cathode-ray tubes, operation of X-Y recorders and other equipment, recording for delayed display and analysis, 3-D operation, as well as audio/visual "conversation" with a remote terminal. Material drawn, written or marked on the Tablet with the Stylus yields a permanent copy and is

simultaneously digitized by **hypersonic ranging**, a new encoding principle, at rates up to 200 co-ordinate pairs per second and a resolution of 2000 x 2000 line pairs. The sensing rate is variable to match the user's speed and for efficient use of communications circuits and computer capacity. Output data, at TTL levels, are available in binary or BCD. A wide variety of interfaces can be supplied for various peripherals and computers. Investment in a SAC **graf/pen** is a fraction of that for similar equipment offering far less precision and versatility. OEM inquiries are welcomed.

description

The **graf/pen** comprises a **Tablet**, a **Stylus**, and a **Control Unit**. For display, a storage CRT or X-Y Recorder may be added.

The **Standard Tablet** has an active area 14 x 14 inches, but any size and shape can be supplied: Frosted (for rear-projection) and transparent plates are available.

Strip Sensors on two sides of the Tablet receive signals from the Stylus.




The **Stylus** combines a ball-point pen with a tiny spark gap; the low-energy spark generates the sonic pulse with an extremely fast risetime used in the hypersonic ranging, and a small fraction of the energy provides the operator with a useful audible feedback. The Stylus is used with the Tablet and other Sensor-equipped devices.

The **Control Unit** interprets information from the Sensors indicating the position of the Stylus on the X and Y axes of the Tablet, and discriminates against ambient noise. The data bus uses standard TTL levels. A variety of operating modes is selectable by panel switches.

Free-Standing Sensors are available for use on other devices — such as a CRT, or to digitize from microfilm projection screens, large plotter beds, and other facilities.


Free-Standing Sensors are movable, and can be used to digitize information from original copy of any size.

- CRT Display
- Interaction with a CRT
- Transmission over voice-grade circuits
- Storage for delayed analysis and display
- Cursor Control by Stylus




ORDER NO		2	6	4
DATE		1	3	2
STORE NO		0	0	7
SALESMAN		0	1	3
QUANTITY		PRICE		
DOZ	②	3	4	5
DOZ	1	2	③	4
DOZ	1	②	3	4
UNIT	1	2	3	5
UNIT	1	2	3	5
UNIT	1	2	3	5
UNIT	1	3	6	9
UNIT	1	3	6	9
DOZ	1	6	12	15
DOZ	1	6	12	15


with a standard tabular form, items and quantities are indicated by a touch of the Stylus and digitized — and then, via computer, may be checked against inventory, recorded, and confirmed.



without keyboard, mouse, light pen or cursor, rough sketches or menu-selected symbols are transferred to paper as finished engineering drawings by a **graf/pen**-controlled computer-aided drafting system.




numerical-control machining instructions are digitized directly from the part itself or a shop drawing, and recorded on paper or magnetic tape.



a flow diagram or electronic circuit can be sketched on the Tablet and the component parameters entered into the computer; performance is read out; parameters or dimensions can be altered and new values reported.

[illegible]

rough printed copy is combined with instructions on the Tablet to create finished page layouts which can be duplicated by automated printing equipment.



one-way and two-way
audio-visual
"conversations" via
voice-grade circuit and
with graphical interaction
on CRTs or X-Y recorders.



digitizing visual records such as EKGs, EEGs, Response Curves, Statistical Graphs, and Polaroid photos of transient phenomena, for computer analysis.

[illegible]

Hand-Printed Character Recognition, the interpretation of the dynamics of alpha-numeric characters while being formed by the **graf/pen** Stylus, and conversion to machine-usable form.

operation

Paper placed on the writing surface of the Tablet provides a permanent record of written or drawn input. Standard forms may be marked with the Stylus, or images may be projected from behind onto a frosted plate.

The spark is initiated by the Control Unit, by pressure of the Stylus on the Tablet or CRT face, or by command of a computer. Choice of Operating Mode is made by a switch on the Control Unit Panel.

X-Y Counters and Clock Pulses start with the spark. Fast-risetime soundwaves from the spark propagate through the air to the Sensors and cause the counters to stop; the counters then contain binary numbers proportional to the X and Y distances from the Stylus spark to the Sensors. After these numbers are

settled in the Output Register, an "Output-Ready" pulse is generated and the numbers are available for external equipment (CRT, computer, etc.). Coordinate pairs are generated repeatedly at rates as fast as 200 per second. When the Stylus is moved, different binary numbers are entered in the X and Y Counters.

Inherent characteristics of the Sensors and filtering in the Control Unit limit the sensitivity of the sonic system to the wavefront generated by the spark, and prevent interference by even the highest ambient-noise level found in computer rooms.

Tablets are easily re-oriented for left-handed operators.

The Controls described under SPECIFICATIONS allow for operation in the following modes:

Rep Rate is continuously-variable from one to 200 coordinate pairs per second.

Pen Mode allows continuous digitizing when the Stylus pen is in actual contact with the surface of the Tablet or a paper placed thereon, or the face of a CRT or other sensor-equipped device.

Free-Run Mode has the internal Rep-Rate Control in command, and digitizing continues **even with the Stylus several inches above the surface of the Tablet!**

Single-Shot Mode creates one coordinate pair for each Stylus-tip contact with the Tablet or CRT face.

Remote Mode allows a computer to call for new coordinate pairs.

general specifications

RESOLUTION 2000 X 2000 Line Pairs (0.007" for 14" Tablet)

DATA RATE Variable, one to 200 Word Pairs per second

REPRODUCIBILITY One Least-Significant Bit in 11; or, in BCD version, one count out of 2000.

DIGITAL OUTPUTS

Registers X and Y 11-Bit Binary or 4-Digit BCD, with standard TTL Buffers (also Line Drivers and Open Collector Buffers available)

Output Ready Ground-going Pulse

Pen Control Ground, when Stylus is in contact with Tablet or CRT

CONTROLS (on Front Panel)

Power On/Off

Rate Coordinate-Pair Rate selectable from 0 to 200 pairs per second

Modes Free-Run, Single-Shot, Pen-Control, Remote

Dimmer Continuously-variable, adjusting display brightness for comfort in dim environment

Left Hand/Right Hand Interchanges X and Y axes for more convenient use by left-handed operators

Reset Clears Registers

INDICATORS (on Front Panel)

X and Y Displays (optional) Two groups of 11 light-emitting diodes or, in BCD version, four digits of 7-segment LEDs

Power On

CONNECTORS

Front Panel For Stylus and Sensor Cables

Back Panel Output Connector for X Data and Y Data; X and Y Register Overflows; Output-Ready (program interrupt); Pen Control (Z axis); External Reset

TABLET (standard) Useful area 14" x 14" (other sizes available); clear or frosted plates available.

specifications subject to improvement without notice

Please send me information on the GRAF/PEN as it applies to:

- ☐ Business Data Entry
- ☐ Printed Page Make-Up
- ☐ Mapping
- ☐ Medical Data
- ☐ Data Reduction
- ☐ Census Analysis
- ☐ Other

- ☐ Interactive Graphics
- ☐ High Energy Physics
- ☐ Light Pen Replacement
- ☐ CRT Photo Digitization
- ☐ Speech Synthesis
- ☐ Architectural Design
- ☐ Quality Control

- ☐ I would like a demonstration.
- ☐ Have a Sales Engineer contact me.
- ☐ Add me to your mailing list.

My interest is:

- ☐ for an active project
- ☐ updating my files

☐ general interest

NAME _____ TITLE _____
COMPANY _____ DEPT. _____
STREET _____ CITY _____ STATE _____ ZIP _____
COUNTRY _____ PHONE (Area Code) _____ EXT _____

FIRST CLASS
PERMIT
No. 43
SOUTHPORT, CONN.

BUSINESS REPLY MAIL

FIRST CLASS
PERMIT
No. 43
SOUTHPORT, CONN.

Postage will be paid by

**SCIENCE
ACCESSORIES
CORPORATION**

65 STATION STREET / SOUTHPORT / CONNECTICUT / 06490 / USA



SCIENCE ACCESSORIES CORPORATION

65 STATION STREET
SOUTHPORT
CONNECTICUT 06490
MAY 1971

PHONE (203) - 255-1526

Dear Sir:

We appreciate your interest in the Graf/Pen as a means to solve your input problems. Additional information is enclosed with this letter so that you can determine more directly how the Graf/Pen applies to your needs.

Our local representative, identified below, will be happy to answer your questions or arrange for a demonstration.

SAC offers Graf/Pen interfaces for off-line devices (tape punch, incremental magnetic tape drive, card punch, Teletype, storage-type CRT, X-Y recorder) and for hard-wire to computers. For keyboard or menu selection, either alone or combined with graphics, Graf/Pen accessories can generate digital codes to reproduce your alphanumerics, symbols and instructions. Please send us details on your system requirements.

We would be pleased to submit a quotation on larger quantities of the Graf/Pen, and on simplified packaging of components for inclusion in your system. There is a considerable price reduction for continuing contracts and simplified component specifications. We invite you to submit a description of your requirements and probable quantities.

More detailed information is available on current Graf/Pen applications. Please fill in the enclosed reply card so that we can continue to serve your needs.

Sincerely,

Rolf Kates
Director of Marketing

RK/ljw

Enc. GP-2 Brochure
Reply Card

cc: Inquiry File
Reader's
LHH
Rep

Your sales representative is:

MR. GEORGE SCHWAMB
COMPONENT SALES CORPORATION
221 EAST HARTSDALE AVENUE
HARTSDALE, NEW YORK 10530